



INSTALLATION AND USER MANUAL

Reliance Valves 240V Wired Programmable Thermostat



AN RWC BRAND



Contents

Thermostat specification	1
Important safety information	2
Display	3
Time setting	7
Programme setting	8
Operation mode	9
Alarm instructions	10
Installation	11
Wiring diagram	12
Configuration Menu	13
Connecting the App	17

Specification

Power source: 100-240VAC 50/60Hz

Load current output: 250VAC 3(2)A

Temperature setting range: 5~35°C


Display accuracy: 0.1°C

Setting accuracy: 0.5°C

Storage temperature: -10~60°C, 0~90%RH

Ambient temperature: 0~50°C, 0~80%RH

Wifi frequency: 2.4GHz



Important safety information

Read all of the information in this manual before installing this thermostat.

Always turn off the power at the main power source by unscrewing the fuse, or switching the circuit breaker to the off position before installing, removing, cleaning, or servicing this thermostat.







Only a professional contractor should install this thermostat.



All wiring must conform to local and national building and electrical codes and regulations.

If the system is not operating properly, check the wiring and replace the fuse if necessary.


Use this thermostat only as described in this manual.


Thermostat display

- a  ON/OFF/Boost
- b  Time setting
- c  Menu button
- d  Lower temperature setting
- e  Raise temperature setting
- f  Reset



Thermostat display

- 1 If the icon  is not shown then WiFi is not connected
If the signal is lost after connection the icon will flash
- 2 Weeks icon
- 3 Mode: Room mode, floor mode, dual temperature mode
- 4 Room temperature/time display
- 5 Manual mode
- 6 Programming mode
- 7 Key lock
- 8 Boiler on/off
- 9 Frost protection
- 10 Holiday mode
- 11 Settings menu
- 12 AM/PM
- 13 Sleep mode
- 14 Away mode
- 15 Back home mode
- 16 Wake up
- 17 Temperature setting/
Boost display



ON/OFF function

Press '⏻' to turn the thermostat ON. Press and hold '⏻' again to turn the thermostat OFF.

Key lock function

In the main display interface, press and hold '⏻' '⏮' '⏭' at the same time to activate or cancel the key lock. When activated, no keys can be used. The thermostat will display '🔒'.

Boost function

Press '⏻' to switch the setting temperature or boost control. When the display shows '+0', press '⏻' '⏮' to select boost. The length of time the heating will be boosted is displayed. When the time elapses the screen returns to the temperature display.

Press '⏻' to cancel and go back to the temperature display setting.

Holiday mode

With the power on, press '☰' to switch between manual mode, programming mode and holiday mode. After selected holiday mode '🏠' will display and will run at 16°C. Press '☰' to cancel holiday mode.

Boost function can be used during holiday period.

Open window function

If the room temperature drops 6°C in 4 minutes, the open window function will activate and display '[]', then turn down all heating. When the room temperature increases by 2°C the thermostat will return to normal operation. Press any button to cancel the open window function while it is active.

Anti-seize function

If the thermostat has not been activated for over 1 week then to prevent the valve and pump from seizing, the thermostat will run the system for 5 minutes.

Frost protection

In frost protection mode, when the temperature drops below what has been selected, the thermostat will start the heating until the temperature has been raised by 3°C.

Intelligent function

The intelligent function adjusts the starting time for home heating according to the temperature measured within the building. It preheats your rooms to the temperature according to your schedule.

Time Proportional and Integral (TPI) display

The TPI function increases boiler efficiency by firing the boiler at regular intervals, adjusting firing duration with demand, to maintain set room temperatures. It can provide great cost savings.

Time setting

Press and hold '⌚' for 4 seconds, press '⌚' to select year, month, day, time scale, time, press '▼' '▲' to adjust setting, press '⌚' to confirm.

If there are no actions for 10 seconds, the thermostat will return to temperature display mode.

Press '⌚' to check time, year, month, day.

Setting the date and time on initial start up

Plug in the power supply. Press '▼' or '▲' to set year, press '⌚' to set month, day, time scale, time, press '▼' '▲' to adjust the setting.



Year



Month



Day



12h/24h optional



Time

Programme setting

Programme setting: 4/6 period programming optional (factory default: 6 period).

When thermostat is on, press and hold '≡' to enter the programming mode. Press '∨' or '∧' to select the programming week (5+2, 5+1+1 or 7 individual day optional).

Press '≡' to enter time setting mode. Press '∨' or '∧' to select time, press '≡' to enter temperature setting mode, Press '∨' or '∧' to select temperature. Press '≡' to save and exit. If no buttons are pushed for 10 seconds, the thermostat will exit program setting automatic.

Default programming (6 period programming)

					
Wake up	Away	Back home	Away	Back home	Sleep
6:00 20°C	8:00 16°C	11:00 20°C	14:00 16°C	18:00 20°C	22:00 16°C

(4 period programming)

			
Wake up	Away	Back home	Sleep
6:00 20°C	8:00 16°C	18:00 20°C	22:00 16°C

In programming state, press and hold '∨' '∧' at the same time to restore factory settings, display 'dEF'

Operation mode

Programming mode (The factory default is programmable)

The thermostat will run according to the pre-set schedule. The screen will show '🕒'

Manual mode

From programming operation mode, press '☰' to enter the manual mode, the screen will display '👉'. Press '^' or 'v' to immediately adjust the temperature and save automatically.


Temporary hold mode

The thermostat will keep the room at the temporary set temperature, and will resume the programme operation mode when you enter the next programme. In programming operation mode, press '^' or 'v' to enter the temporary hold mode, the screen display '👉🕒'. Press '^' or 'v' to immediately adjust the temperature and save automatically.

Alarm instructions

Err. display	Err. condition	Result
Er 1	Internal sensor short circuit	Thermostat shut down all heating output
Er 2	Internal sensor open circuit	Thermostat shut down all heating output
Er 3	External sensor short circuit	Thermostat shut down all heating output
Er 4	External sensor open circuit	Thermostat shut down all heating output

Installation



1 Install the base


2 Mounting screws

3 Install the panel



4 Finish

Wiring diagram

Wiring diagram for 230V connections:
 Power: 100-240VAC 50/60Hz
 I_{max}: 3(2)A



Wiring diagram for volt-free connection (e.g. boiler control)



Suggest cable is not over 1.5mm

Configuration menu

With the thermostat turned off, press and hold '≡' to enter the configuration menu. Press '≡' to select different parameters. Press '^' 'v' to adjust parameters. Press and hold '≡' for 3 seconds, display 'dEF', indicates all the configuration settings have reverted to factory default setting. The thermostat will return to 'OFF' mode if no buttons are pushed within 10 seconds.

Item	Press button	Displayed (factory default)	Press v or ^ to select	Descriptions
1	≡	CL (00°C)	-6°C ~ +6°C	Temperature correction value
2	≡	RH (35°C)	20°C ~ 50°C	Select maximum setting temperature
3	≡	RL (50°C)	5°C ~ 20°C	Select minimum setting temperature
4	≡	bL (2)	1/2	Backlight mode 1: Backlight always bright 2: When a button is pressed, the backlight is bright for 15 seconds

Configuration menu

Item	Press button	Displayed (factory default)	Press \downarrow or \uparrow to select	Descriptions
5	≡	db (05 ^{°C})	0.2°C - 5°C	When the temperature is < room temperature - setting value, the heating will stop. When the temperature is < room temperature + setting value, the heating will start.
6	≡	Pr (On)	ON/OFF	Program option ON/OFF
7	≡	SE (6)	4/6	Select Programming period in one day 6-6 time zones; 4-4 time zones
8	≡	ES (OFF)	On/OFF	Intelligent function option ON : Turn on intelligent function OFF : Turn off intelligent function
9	≡	OP (OFF)	On/OFF	Open window function option ON/OFF

Configuration menu

Item	Press button	Displayed (factory default)	Press \downarrow or \wedge to select	Descriptions
10	≡	<i>RF (ON)</i>	On/OFF	Frost protection option ON/OFF
11	≡	<i>PP (100°C)</i>	5°C-17°C	Frost protection temperature setting
12	≡	<i>PI (ON)</i>	On/OFF	TPI function option: ON/OFF
13	≡	<i>RL (ON)</i>	On/OFF	Anti-seize function selection: ON/OFF
14	≡	<i>bH (NC)</i>	nC/nO	Select the actuator type NC/NO
15	≡	<i>S_n (100)</i>	100/10	External sensor 100 : NTC100K 10 : NTC10K
16	≡	<i>Et (Sr)</i>	Sr/SF/rF	External sensor function option Sr : room mode rF : room and floor mode SF : floor mode

Configuration menu


Item	Press button	Displayed (factory default)	Press \downarrow or \uparrow to select	Descriptions
17	≡	Pt (27.0°C)	6 – 45°C	Select maximum floor setting temperature limitation
18	Press 'OK' to confirm and exit.			

Note item 14, if connected to a wiring centre all actuators should be the same configuration.

Connecting the App

Download and register

Click App store (click Android application market)
Search for 'Reliance Controls' and download




Login

When you finish the registration, log into your email and click on the link to activate your account. Your APP is now ready to use.


Registered mailbox /phone number


Insert your password




First, please turn on the location of your phone

Before adding the thermostat to your app, make sure to turn off the thermostat and then press and hold '⏻' for 3 seconds, the thermostat display will show '— —'. Then go to the Reliance Controls app.







- 1 Click '+' on the top right



- 2 Click 'Wired thermostat'




- 3 Select your home Wi-Fi, and enter password, then click 'Next'



4 Adding device



5 Added successfully




Temporary leaving mode:

If you are away from home temporarily, click the 'Away' button, the temperature will remain at 16°C, the energy-saving icon '🌿' turns green and is on.

After you arrive at home, click the button again to recover the previous temperature setting.

Press '^', 'v' to adjust temperature

Slide to power on/power off




Click the 'Program' to enter the programming mode

Click the 'History' for checking the history

Click the 'Setting' for setting implicit parameters


APP Setting-Multi-day Programming





Click '7 Day' to select the date

- 1 Click the 'Program' to enter the programming mode
- 2 Slide up and down to select the time, press '^' 'v' to set temperature in different periods of time
- 3 Click 'Submit' to confirm

Click 'Confirm' after selecting the date




Optional Parameter Setting



Slide up and down to select different optional parameters


History



Click here to check the history



Remove devices



Voice command:

After waking up the speaker you can say

Amazon Alexa

- * Alexa, turn on bedroom.
- * Alexa, turn off bedroom.
- * Alexa, raise the bedroom by 1 degree.
- * Alexa, drop the bedroom by 1 degree.
- * Alexa, set the bedroom to 16 degrees.

Google Assistant

- * Ok, Google, turn on bedroom.
- * Ok, Google, turn off bedroom.
- * Ok, Google, set the bedroom to 16 degrees.

Tips:

Bedroom is the device name. You can name it during the device set up.
The temperature graduations and format must be the same in the speaker and the thermostat.



**Reliance Worldwide
Corporation (UK) Limited**

Horton Road
West Drayton
UB7 8JL
United Kingdom
Tel: +44 (0) 1895 449233

Reliance Worldwide Corporation
(UK) Limited reserves the right
to make changes to the product
which may affect the accuracy
of information contained in
this leaflet.

www.reliancevalves.com



RWC/VER3122

AN RWC BRAND
RWC