


# MAPEHEAT THERMO TOUCH

Installation Guide



## Table of content

Dimensions	3
Installation	4
Description	7
Using the Thermostat	7
Installer Menu	8
Warning	8







## DIMENSIONS





# INSTALLATION



⚠ Do not use contactor without suppression device.







## DESCRIPTION

The **Mapeheat Thermo Touch** Thermostat is a Programmable Thermostat designed for Electrical Floor Heating. The Thermostat has 2 programmes to choose from:





- Manual ON/OFF (Constant Single temperature)
- Timer programme (4 timer events/day)



- 1** Temperature
- 2** Sensor symbol
- 3** Heating symbol
- 4** Menu button
- 5** Left button
- 6** Right button

- 7** THERMO TOUCH button
- 8** Day
- 9** Clock button
- 10** Time
- 11** Event symbol

## USING THE THERMOSTAT

- Touch the „“ button to set the clock and day of the week
- Touch the „“ button for 3 seconds to program the timer programme
- Touch the „**M**“ button for 5 seconds to enter the Installer Menu
- Touch the „“ button to switch from Timer to Manual ON/OFF mode
- Touch the „“ button for 2 seconds to put the Thermostat into OFF (standby) mode

## INSTALLER MENU

#	Description
1	Sensing mode selection
2	12 vs 24 hours display
3	Motion sensor. When getting close to the thermostat (5 cm range) the display lights up automatically
4	Offset for floor sensor calibration
5	Room sensor calibration
6	Minimum temperature set point for the Floor Sensor
7	Maximum temperature set point for the Floor Sensor
8	Minimum temperature set point for the Room Sensor
9	Maximum temperature set point for the Room Sensor
10	Adjustable hysteresis
11	Window open function. If the thermostat feels a sudden drop in temperature, the heating will be stopped for 30 minutes and the Home symbol will blink.

## WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

TECHNOLOGY FROM



**MAPEI WORLD LONDON CITY**

6 Great Sutton Street  
Clerkenwell  
London  
EC1V 0BX  
020 3302 9610  
clerkenwell@mapei.co.uk

**MAPEI UK LTD**

Mapei House  
Steel Park Road  
Halesowen  
West Midlands, B62 8HD  
0121 508 6970  
info@mapei.co.uk



0121 508 6970 | mapei.co.uk

